

INSTRUCTION MANUAL

thanks for your choice on our products. It is very easy to use our product, please read the manual just before using it:

Spec :

g	oz	ct	ozt	dwt	gn
500g/0.1g	17.6oz/0.01oz	2500ct/0.5ct	16.1ozt/0.01ozt	322.00dwt/0.1dwt	7716/1gn
300g/0.01g	10.56oz/0.001oz	1500.00ct/0.05ct	9.660ozt/0.001ozt	193.20dwt/0.01dwt	4629.6/0.1gn
200g/0.01g	7.04oz/0.001oz	1000.00ct/0.05ct	6.440ozt/0.001ozt	128.80dwt/0.01dwt	3086.4/0.1gn
100g/0.01g	3.52oz/0.001oz	500.00ct/0.05ct	3.220ozt/0.001ozt	64.40dwt/0.01dwt	1543.2/0.1gn
1000g/0.1g	35.2oz/0.01oz	5000ct/0.5ct	32.20ozt/0.01ozt	644.0dwt/0.1dwt	15432/1gn

Maximum metage:

Automatically turning off:	1 minutes
Operation temperature:	10℃-30℃
LCD display:	5 digit display
Backg light:	blue (other options)
Dimension:	128x78x19mm
Power	2X"AAA" batteries
Weight:	128g
Super stainless tray:	69x64mm

Tare function

Automatically & low-energy-consuming alarming system

Option units: g/oz/ozt/dwt/ct/gn

Instruction:

1. Press the "ON" key, and wait for 5 seconds for 0.0;
2. Put the article on to the tray, when "S" appears, the display means the weight of the article.
3. Change the measuring unit by using the MODE key.
4. Press the TARE key to reset the 0 calibration.
5. OFF means shut down.
6. calibration function:

Press the button "ON/OFF", Press down MODE key and don't put after switch on, Showing to hold will appear CAL; Click the MODE key once again, Showing to hold will show a weights(500G); Put up to should the code, after 5 second, Showing to hold will show PASS; Revise be over at this time. (You should calibrate the scale when the temperature change or other reasons).

Notice:

Remove the protection cover of the tray gently; the SCALE should be kept in a stable and windless condition.

Never put on the tray the weight over the rated one, or the sensing part will be damaged; when applying the article, please conduct it in a gentle way.

Do not making the phone call in a range of 50cm when using our product., or it will affect the result.

When there is an S appears in the left & up corner, the display means the weight of the article

The there is the symbol of the battery appears in the display, it means you need to change battery.

Please use our product in a condition of 10℃-30℃; a difference in temperature may cause error. If the is a noticeable difference, please use a weight to calibrate it. When doing this, a 30 minutes' using time must be guaranteed

in a same surrounding.

When overload, an "FULL." will appear.

Please take good care of the scale

January-2012 Change Version